

Instruction manual | EASYFIX 4



Wood construction screws: General connection

General information:

Data input:

3D Model:

Results:

1. General information

2.1 Connection elements - wood

2.2 Connection elements - screws

3. Loads

4. 3D Model

5. Screw filter

6. Detailed analysis

7. Calculation report



- move to a selected issue



- back to the table of contents


Instruction manual | EASYFIX 4




Wood construction screws: General connection


General information

Category and module selection:



Icons and symbols meaning:





Click to **information icon** to display an additional window containing theory related to a particular issue.




Data input
Connection elements - wood

First, define layout of elements as well their dimensions in cross section along with possible distance from their edges. Next, determine the type and strength class of the wooden material.

Geometry and layout of elements:: dimensions can be defined in the side panel and directly on a model as well.

Material:

Inputting data by selection from the list.






Data input
Connection elements - screws

Installation parameters:

Inputting data by selection from the list or setting additional options.

Further stage is defining of screws layout. Note, that selected layouts and installation types are dedicated for particular types of screws. Depending on a selected layout, possibilities of load change as well. Detailed data is available by clicking the information icon.





Data input Loads

>>


Loads:

Load values can be defined in the side panel and directly on the model as well.

Load combinations:

Design load values for particular load combinations are presented at the bottom part of the panel.

The final stage of data input is related to loads. In accordance to intended use, wood construction screws are dedicated for static or quasi static loads only. Define characteristic values of permanent and variable loads, service class and load effect duration class as well.





3D Model

»

Geometry:

Dimensions can be defined in the side panel and directly on a model as well.

Loads:

Load values can be defined in the side panel and directly on a model as well.


Screws layout:

Designed layout is presented on a model with spacings and edge distances.

Model navigation:

Model navigation utilises mouse control or default views.

Dynamic 3D model provides a User with a possibility of following results in real time.





Results Screw filter

>>

Screw filter:

Using available filters allows to pre-define screws.

Designed product / Screw system: Information about design solution are presented in the middle part of the panel.


Utilisation:

Basic data of utilisation of design solution is presented at the bottom part of the panel.

Comments:

In case of no result, a comment with information about the reason is dispalyed.

General connection module is ment to select optimised number of the fasteners, their sizes and arrangement as well. Result can be managed by available filters. In case of no result, a comment with information about the reason is displayed. In such situation change of screw layout (straight/inclined/crossed) or modification of the filters should be considered.





Result
Detailed analysis


>>

Detailed analysis allows to check utilisation level for particular failure modes. Defining crucial element helps analysing a case. Detailed information related to all failure modes are available via information icon.

Designed product / Screw system: Information about design solution are presented in the upper part of the panel.

Utilisation:

Detailed data of utilisation of selected failure modes are presented at the bottom part of the panel.





Results
Calculation report

>>

Print option:

Report language can be defined independently of software language that had been used for calculation process.

Print description:


Detailed description helps to identify the calculation at a later stage of work. This information is visible on the header of each report page.

File path:

Selecting the print file save destination.

Drawing:

In the Drawing panel, it is possible to modify the final model view, that is presented in the printed version of the report. Generating a project report is started by clicking on the Print icon. Next, specify the language of the report along with a possible description. The report is printed to a pdf file, in a destination selected by a Customer.







Result

Calculation report





Design report includes all information concerning selected design, input data, loads, spacings and edge distance requirements. There are full calculation logs presented along with references to paragraphs concerning appropriate design guidelines.







EasyFin4 v. 4.4.10 - General connection TES	T VERSION 1fc1810b2		■ EasyFix	Easyfi
ojecti Isjecti Kofessi Ecsladiosa — e-mail radiolasa administratojo com — Baselging		Date: 2021-09-22 Organization: Address: Contact:	Page: 5/7	Project: Subject: Address Calculat by Ravij
cz				
mod 736 F _{44,0,3} 7 1.3 24354N	thed N _{Ed}	_		
		LC1	LC2	
Tensile failure of the screw		β _{N4} = 1.6%	β ₈₄ = 1.6%	$F_{i,0i} =$
$i_{Ed} \le \frac{F_{I,R0}}{\gamma_{Id}}$				
$i_{Ak} = m_{ef} \cdot f_{beau,k}$				
f from F _{1,80}	237	F _{t,M}		
2 23.3 kN 116.87 ki	* 13	20.7 64		a)
n m Fin	N_{Ed}			∫6.1.A 15.38 MPG
1.87 in 1.3 893 in 2	1.35 kN			b)
in to Fine	N_{Ed}			FL2A TUSHMPA
874N 1.3 89.94N	1.35 kN	_		0
		LC1	LC2	fs.s.a 1538 MPa
Buckling of screw in element [1]		β _{res} = ND	β _{NS} = ND	0
				fs.1.6 75.38 MAG
Buckling of screw in element [2]		LC1	LC2	e) fala
		β _{N4} = ND	β _{ne} = ND	75.1.4 15.38 MPG
Lateral load (EN 1995-1-1:20	04+AC:2006+A1	:2008; section 8.7.1; ETA12,	(3456)	LC1
Shear failure modes		LC1	LC2	F _{c,Rk}
		β ₁₁ = 92.3%	β _{ν1} = 79.1%	LC2 F _{r,00}
$i_{\ell,d} \le m_{ef} \cdot k_{mod} \cdot \frac{F_{r,E0}}{\gamma_M}$				F _{0,0k} 22 kN
National regulations, em	vironmental and application	conditions must be considered when designing t	he anchorage.	












Instruction manual | EASYFIX 4




Wood construction screws: General connection

Have you got any questions?

Visit EasyFix website or contact directly with Rawlplug Technical Department via Rawlplug Technical Helpdesk.





https://www.rawlplug.com/en/services/technical-helpdesk#/





